




## CMD STUDIO 4a MAPPING FOR CROSS DJ



1	BROWSE THE ACTIVE BROWSABLE	37	MASTER VOLUME
2	CHANGE THE ACTIVE BROWSABLE	93	CROSSFADER
2	+ DEL BROWSE SAMPLE BANK LIST (SAMPLER C)	KNOB UNDER 68	CUE/MIX
3	CHANGE THE ACTIVE BROWSABLE	KNOB UNDER 69	MONITOR VOLUME
3	+ DEL BROWSE SAMPLE BANK LIST (SAMPLER D)		
4	PERFORM THE PRIMARY ACTION ON ACTIVE BROWSABLE		
4	+ DEL LOAD SELECTED SAMPLE BANK (C or D)		
76	LEVEL MASTER LEFT		
76	LEVEL MASTER RIGHT		

## PLAYERS A/C

5		FX1 AMOUNT
6		FX1 DEPTH
7		FILTER A/C
8		AUTOLOOP SELECT A/C
9		FX1 ON/OFF
9	+ DEL	FX1 SELECT
10		FX1 INPUT CHANNEL = MASTER
11		FILTER ON/OFF A/C
12		AUTOLOOP TRIGGER A/C
70		LOAD A/C
70	+ DEL	RELOAD AS CLONE OF MASTER A/C
72		FX1 INPUT CHANNEL = A/C
73		FX2 INPUT CHANNEL = A/C
16		LOOP IN
16	+ DEL	LOOP HALVE
17		LOOP OUT
17	+ DEL	LOOP DOUBLE
18		LOOP ON/OFF
18	+ DEL	RELOOP ON/OFF
15		VINYL ON/OFF
15	+ DEL	SLIP MODE
20		PITCH MODE
20	+ DEL	PITCH RANGE
22		PITCH VALUE
23		PITCH BEND DOWN
23	+ DEL	KEY SEMITONES (-)
24		PITCH BEND UP
24	+ DEL	KEY SEMITONES (+)
21		JOGWHEEL PITCH BEND +/-
21		JOGWHEEL SCRATCH
21	+ DEL	SMART-SEEK
25		LOCATOR 1 CONTROL
25	+ DEL	LOCATOR 1 CLEAR
26		LOCATOR 2 CONTROL
26	+ DEL	LOCATOR 2 CLEAR
27		LOCATOR 3 CONTROL
27	+ DEL	LOCATOR 3 CLEAR
28		LOCATOR 4 CONTROL
28	+ DEL	LOCATOR 4 CLEAR
29		LOCATOR 5 CONTROL
29	+ DEL	LOCATOR 5 CLEAR
30		LOCATOR 6 CONTROL
30	+ DEL	LOCATOR 6 CLEAR
31		LOCATOR 7 CONTROL
31	+ DEL	LOCATOR 7 CLEAR
32		LOCATOR 8 CONTROL
32	+ DEL	LOCATOR 8 CLEAR
33		MODIFIER 1

34		CUE
34	+ DEL	NEEDLE SEARCH = 0
35		PLAY/PAUSE
35	+ DEL	CUE/PLAY
36		SYNC WITH MASTER
36	+ DEL	SET AS MASTER
77		TREBLE A/C
77	+ DEL	GAIN A/C
78		MID A/C
79		BASS A/C
80		KILL TREBLE A/C
81		KILL MID A/C
82		KILL BASS A/C
89		CUE MONITOR A/C
91		VOLUME A/C
13		SWITCH PLAYER A
14		SWITCH PLAYER C
14	+ DEL	SWITCH PLAYER C / SAMPLER C

## SAMPLER C

18		CLOCK START/STOP
16		CLOCK DOWN
17		CLOCK UP
23		CLOCK BEND DOWN
24		CLOCK BEND UP
36		SYNC WITH MASTER
36	+ DEL	SET AS MASTER
15		TRIGGER NEW HOT SLICING BANK
25		PAD 1 CONTROL
25	+ DEL	PAD 1 MODE
26		PAD 2 CONTROL
26	+ DEL	PAD 2 MODE
27		PAD 3 CONTROL
27	+ DEL	PAD 3 MODE
28		PAD 4 CONTROL
28	+ DEL	PAD 4 MODE
29		PAD 5 CONTROL
29	+ DEL	PAD 5 MODE
30		PAD 6 CONTROL
30	+ DEL	PAD 6 MODE
31		PAD 7 CONTROL
31	+ DEL	PAD 7 MODE
32		PAD 8 CONTROL
32	+ DEL	PAD 8 MODE

## PLAYERS B/D

38		FX2 AMOUNT
39		FX2 DEPTH
40		FILTER B/D
41		AUTOLOOP SELECT B/D
42		FX2 ON/OFF
42	+ DEL	FX2 SELECT
43		FX2 INPUT CHANNEL = MASTER
44		FILTER ON/OFF B/D
45		AUTOLOOP TRIGGER B/D
71		LOAD B/D
71	+ DEL	RELOAD AS CLONE OF MASTER B/D
74		FX1 INPUT CHANNEL = B/D
75		FX2 INPUT CHANNEL = B/D
50		LOOP IN
50	+ DEL	LOOP HALVE
49		LOOP OUT
49	+ DEL	LOOP DOUBLE
51		LOOP ON/OFF
51	+ DEL	RELOOP ON/OFF
48		VINYL ON/OFF
48	+ DEL	SLIP MODE
53		PITCH MODE
53	+ DEL	PITCH RANGE
55		PITCH VALUE
56		PITCH BEND DOWN
56	+ DEL	KEY SEMITONES (-)
57		PITCH BEND UP
57	+ DEL	KEY SEMITONES (+)
54		JOGWHEEL PITCH BEND +/-
54		JOGWHEEL SCRATCH
54	+ DEL	SMART-SEEK
58		LOCATOR 1 CONTROL
58	+ DEL	LOCATOR 1 CLEAR
59		LOCATOR 2 CONTROL
59	+ DEL	LOCATOR 2 CLEAR
60		LOCATOR 3 CONTROL
60	+ DEL	LOCATOR 3 CLEAR
61		LOCATOR 4 CONTROL
61	+ DEL	LOCATOR 4 CLEAR
62		LOCATOR 5 CONTROL
62	+ DEL	LOCATOR 5 CLEAR
63		LOCATOR 6 CONTROL
63	+ DEL	LOCATOR 6 CLEAR
64		LOCATOR 7 CONTROL
64	+ DEL	LOCATOR 7 CLEAR
65		LOCATOR 8 CONTROL
65	+ DEL	LOCATOR 8 CLEAR
66		MODIFIER 1

67		CUE
67	+ DEL	NEEDLE SEARCH = 0
68		PLAY/PAUSE
68	+ DEL	CUE/PLAY
69		SYNC WITH MASTER
69	+ DEL	SET AS MASTER
83		TREBLE B/D
83	+ DEL	GAIN B/D
84		MID B/D
85		BASS B/D
86		KILL TREBLE B/D
87		KILL MID B/D
88		KILL BASS B/D
90		CUE MONITOR B/D
92		VOLUME B/D
46		SWITCH PLAYER B
47		SWITCH PLAYER D
47	+ DEL	SWITCH PLAYER D / SAMPLER D

## SAMPLER D

51		CLOCK START/STOP
50		CLOCK DOWN
49		CLOCK UP
56		CLOCK BEND DOWN
57		CLOCK BEND UP
69		SYNC WITH MASTER
69	+ DEL	SET AS MASTER
48		TRIGGER NEW HOT SLICING BANK
58		PAD 1 CONTROL
58	+ DEL	PAD 1 MODE
59		PAD 2 CONTROL
59	+ DEL	PAD 2 MODE
60		PAD 3 CONTROL
60	+ DEL	PAD 3 MODE
61		PAD 4 CONTROL
61	+ DEL	PAD 4 MODE
62		PAD 5 CONTROL
62	+ DEL	PAD 5 MODE
63		PAD 6 CONTROL
63	+ DEL	PAD 6 MODE
64		PAD 7 CONTROL
64	+ DEL	PAD 7 MODE
65		PAD 8 CONTROL
65	+ DEL	PAD 8 MODE