


**DENON - DN-MC6000**



- 1 - FX Select
- FX Amount
- FX Depth
- Brake time
- 2 - FX On/Off
- Echo On/Off
- Flanger On/Off
- Roll On/Off
- 3. 4 - FX channel
- 5 - Pitch mode - *Pitch Range*
- 6 - Manual loop

- 7 - Auto loop - *Loop On/Off*
- 8 - Locators / Pads
- 9 - Shift
- 10 - Sampler
- 11 - Jog
- 12 - Seek - *Seek lenght*
- 13 - Cue - *Set Cue*
- 14 - PlayPause - *CuePlay*
- 15 - Pitch bend
- 16 - Sync - *Match*
- 17 - Pitch

- 18. 19 - Filters
- 20. 21 - Slip mode
- 22 - Load - *Clone*
- 23 - Browse - Expand - Collapse - Preview
- 24 - Change active browsable
- 25 - Record
- 26 - Show/Hide FX
- 27 - Show/Hide Samplers
- 28 - Expand Collapse collection